

Switch - Modules SFP tiers

Commandes pour activer le support de modules SFP tiers :

```
service unsupported-transceiver  
no errdisable detect cause gbic-invalid
```

Revision #1

Created 2025-04-04 14:15:38 UTC by Axolito

Updated 2025-04-04 14:16:31 UTC by Axolito