

Switch - Modules SFP tiers

Commandes pour activer le support de modules SFP tiers :

```
service unsupported-transceiver  
no errdisable detect cause gbic-invalid
```

Revision #1

Created 4 April 2025 14:15:38 by Axolito

Updated 4 April 2025 14:16:31 by Axolito